

Sharp Ar 141s Ar 141g Digital Copier Parts List Manual

SHARP PARTS GUIDE

CODE: 00ZAR5132PG-M



DIGITAL COPIER

MODEL **AR-5132**

CONTENTS

- | | |
|---|--|
| 1) Extensor | 22) ADU section 2 |
| 2) Operation panel | 23) RADF: Extensor |
| 3) Rear Extensor upper | 24) RADF: Paperfeeding tray section |
| 4) Optical section | 25) RADF: Transport part section |
| 5) Dry lamp section | 26) RADF: Paperfeeding transport section 1 |
| 6) 2nd.3rd Mirror roller section | 27) RADF: Paperfeeding transport section 2 |
| 7) Front frame Left | 28) RADF: Reversion transport section |
| 8) Front frame Right | 29) Deck: Extensor |
| 9) Rear frame 1 | 30) Deck: Transport section |
| 10) Rear frame 2 | 31) Deck: Paperfeeding Jam cover section |
| 11) Optical frame 1 | 32) Deck: UCC Paper feeding section |
| 12) Optical frame 2 | 33) Deck: Rear frame |
| 13) Drum (cassette) section | 34) Deck: Drive section |
| 14) Toner hopper section | 35) Deck: UCC tray section |
| 15) Developing section | 36) Deck: tray (dup) section |
| 16) Fusing section | 37) Deck: Cassette assembly (drawer) section |
| 17) Delivery turn over section | 38) Deck: packing material & Accessories |
| 18) Vertical transport section | 39) Packing Material & Accessories |
| 19) Transport section | 40) ICU PWB |
| 20) Transport DV guide section | 41) PCU PWB |
| 21) Main drive section | 42) Operation PWB |
| 22) DV drive section | 43) Operation control PWB |
| 23) Paperfeeding speed change section | 44) AC PWB(100V series) |
| 24) Paperfeeding drive section | 45) AC PWB(200V series) |
| 25) 600 tray paper feeding section | 46) NF PWB (200V series) |
| 26) Manual paper feeding multi section | 47) Inverter PWB |
| 27) Manual paper feeding multi tray section | 48) DC Power supply PWB(100V series) |
| 28) MC section | 49) DC Power supply PWB (200V series) |
| 29) TC case section | 50) RADF: Control PWB |
| 30) Cassette drawer section | 51) Deck: Control PWB |
| 31) Inlet cassette section | 52) Index |
| 32) ADU section 1 | |

